Duct sensor for air quality, temperature and humidity (optional)



Datasheet

Subject to technical alteration Issue date: 25.10.2019 • A003





Application

Duct air quality sensor for detection of VOC air quality, and optional humidity combined in one unit. Designed for duct mounted applications with up to 3 0..10 V outputs. The sensor consists of a transmitter with VOC sensor, based on a heated tin oxide semiconductor. With the option board relay two-point controllers or a 2-stage 2-point controller for temperature or humidity can be realized.

Types Available

Duct sensor VOC + temp (opt.) + rH (opt.) - active 1x/2x/3x 0..10 V | 2x 4..20 mA

LK+ VOC V

LK+ VOC VV

LK+ VOC AA

LK+ VOC 3xV

Duct sensor VOC + temp - active 2x 0..10 V + relay

LK+ VOC VV Relay

Options: additional passive temperature sensor

eg: PT100/PT1000/NI1000/NI1000TK5000/NTC10K... and other sensors on request.

Page 2 / 6 Issue date: 25.10.2019

Security Advice – Caution



The installation and assembly of electrical equipment should only be performed by authorized personnel.

The product should only be used for the intended application. Unauthorised modifications are prohibited! The product must not be used in relation with any equipment that in case of a failure may threaten, directly or indirectly, human health or life or result in danger to human beings, animals or assets. Ensure all power is disconnected before installing. Do not connect to live/operating equipment.

Please comply with

- Local laws, health & safety regulations, technical standards and regulations
- Condition of the device at the time of installation, to ensure safe installation
- This data sheet and installation manual

Notes on Disposal



As a component of a large-scale fixed installation, Thermokon products are intended to be used permanently as part of a building or a structure at a pre-defined and dedicated location, hence the Waste Electrical and Electronic Act (WEEE) is not applicable. However, most of the products may contain valuable materials that should be recycled and not disposed of as domestic waste. Please note the relevant regulations for local disposal.

Build-up of Self-Heating by Electrical Dissipative Power

Temperature sensors with electronic components always have a dissipative power, which affects the temperature measurement of the ambient air. The dissipation in active temperature sensors shows a linear increase with rising operating voltage. This dissipative power has to be considered when measuring temperature. In case of a fixed operating voltage ($\pm 0.2 \text{ V}$) this is normally done by adding or reducing a constant offset value. As Thermokon transducers work with a variable operating voltage, only one operating voltage can be taken into consideration, for reasons of production engineering. Transducers 0..10 V / 4..20 mA have a standard setting at an operating voltage of 24 V =. That means, that at this voltage, the expected measuring error of the output signal will be the least. For other operating voltages, the offset error will be increased by a changing power loss of the sensor electronics. If a re-calibration should become necessary later directly on the sensor, this can be done by means of the USEapp software and an optional Bluetooth interface.

Remark: Occurring draft leads to a better carrying-off of dissipative power at the sensor. Thus temporally limited fluctuations might occur upon temperature measurement.

Application Notice for Air Quality Sensors VOC

Unlike CO_2 sensors, which specifically measure CO_2 , mixed gas sensors detect a wide range of gases. The sensor signal does not indicate the type of gas or it's concentration in ppm. Mixed gas sensors detect gases and vapours consisting of carbohydrates, or more generally gases that can be oxidised (burnt): Odours, perfume, cleaning fluid scent, tobacco smoke, new materials fumigations (furniture, carpets, paint, glue ...).

Unlike CO₂, which humans cannot sense, the amount of odours (VOC) indicates the level of air quality. VOC sensors have proven their value in a multitude of applications for many years.

Measuring principle:

Similar to a catalyst converter the organic molecules are burnt (oxidized) when in contact with the sensor's heated -dioxide surface, adding a small amount of heat combustion. The increased temperature is measured providing a signal proportional to the number of molecules being burnt. CO₂ cannot be detected as it cannot be further oxidized.

Refrain from touching the sensor's element sensitive surface. Touching the sensitive surface element will void warranty.

Information about Calibration VOC

Similar to a catalyst converter the VOC sensor will deteriorate over time, which will affect the sensitivity. This VOC sensor automatically compensates the decrease in sensitivity by dynamic auto-calibration.

The reference level of air quality is derived from the ambient conditions over a 72h period. The lowest reading within this 72h time period will be used as reference level, representing the "clean and fresh air level".

Issue date: 25.10.2019 Page 3 / 6

Technical Data

| Measuring values | VOC, temperature + humidity (depending on the device) | |
|--------------------------|--|--|
| Output voltage | 13x 010 V or 05 V, min. load 10 k Ω (live-zero configuration via Thermokon USEapp) | |
| Output Amp | AA $2x 420 \text{ mA}$, max. load 500Ω | |
| Output passive | passive Options: additional passive temperature sensor eg: PT100/PT1000/NI1000/NI1000TK5000/NTC10K and other sensors on request | |
| Output switch contact | Relay 2 floating contacts for 24 V ~ or 24 V = / 3 A | |
| Power supply | VV 3xV Relay 1535 V = or 1929 V ~ | AA 1535 V = |
| Power consumption | max. 2,3 W (24 V =) max. 4,3 VA (24 V ~) | |
| Measuring range temp. | 0+50 °C (default setting), optionally configurable via Thermokon USEapp | |
| Measuring range humidity | 3xV 0100% rH non-condensing, optionally configurable via Thermokon USEapp (enthalpy, absolute humidity, dew point) | |
| Accuracy temperature | V VV AA 3xV Relay ±0,5 K (typ. at 21 °C) | passive depending on used sensor |
| Accuracy humidity | 3xV ±2% between 1090% rH (typ. at 21 °C) | |
| Air speed | min. 0,3 m/s, max. 12 m/s | |
| Calibration | self-calibration | |
| Sensor | VOC sensor (heated metal oxide semiconductor) | |
| Enclosure | enclosure USE-M, PC, pure white, with removable cable entry | |
| Protection | IP65 according to EN 60529 | |
| Cable entry | V VV AA 3xV Flextherm M20, for wire Ø=4,59 mm, removable | Relay M25 with fourfold cable entry for wire with max. Ø=7 mm, removable |
| Connection electrical | removable plug-in terminal, max. 2,5 mm² | |
| Pipe | VV AA 3xV Relay PA6, black, Ø=19,5 mm, length 180 mm | V PA6, black, Ø=19,5 mm, length 150 mm |
| Ambient condition | 0+50 °C, max. 85% rH short term condensation | |
| Mounting | installation is also possible using mounting base | |
| Notes | mixed gas sensors detect gases and vapours which can be oxidised (burnt): Body odours, tobacco smoke, exhalations emitted by materials (furniture, carpets, paint, glue) | |

Configuration



App Store

The Thermokon bluetooth dongle with micro-USB is required for communication between USEapp and USE-M / USE L (Item No..: 668262). Commercial bluetooth dongles are not compatible.

Application-specific reconfiguration of the devices can be carried out using the Thermokon USEapp. The configuration is carried out in the voltage-supplied state.

The configuration-app and the app description can be found in the Google Play Store or in the Apple App Store.

Page 4 / 6 Issue date: 25.10.2019

Application notice




The housing cover must be completely closed in order to ensure the accuracy and reproducibility of the measured values during a test or service log via USEapp.


The Bluetooth dongle snaps into the socket easily. When removing, please fix the plug-in card (option PCB) so that it is not unintentionally pulled out.

Mounting Advices

The sensor can be mounted on the ventilation duct by means of the mounting flange MF20 TPO (optional with mounting base). Align the openings on the sensor tube according to the flow direction.




optional:



Dismounting Advices


Remove the lower section of the sensor carefully and pulling straight out. Pay close attention to the correct dismantling of the component!




Issue date: 25.10.2019 Page 5 / 6


Connection Plan

LK+ VOC V





LK+ VOC VV






LK+ VOC AA







AOI2 }- (temperature | 4..20 mA)
AOI1 }- (VOC | 4..20 mA)


LK+ VOC 3xV









LK+ VOC Relay








Page 6 / 6 Issue date: 25.10.2019

Dimensions (mm)



Accessories (included in delivery)

Mounting flange MF20 Item No. 612562 Mounting kit universal Item No. 698511

Accessories (optional)

Bluetooth dongle
Cable entry M25 USE white, sealing insert 4x Ø=7 mm (4 pcs)
Item No. 668262
Item No. 641364
Mounting base
Filter stainless steel, wire mesh
Sealing insert M20 USE white, 2x Ø=7 mm (for 2 wire; PU 10 pieces)
Item No. 641333

[•] Cover screw + screw cover• 2 Rawlplugs • 2 Screws (countersunk head) • 2 Screws (rounded head)